

## PLC switch

Command	Data type	Description	PS	AX	RW	Range
M_SSEC_UP_PLC_SWITCH_X(x)	T_CHAR	PLC switch X (IN) (x=1 to 32)	--	--	RW	0,1
M_SSEC_UP_PLC_SWITCH_Y(x)	T_CHAR	PLC switch Y (OUT) (x=1 to 32)	--	--	R	
M_SSEC_UP_PLCSW_IN0	T_SHORT	PLC switch X (IN) 1 to 16	--	--	RW	0x0000 to 0xFFFF
M_SSEC_UP_PLCSW_IN1	T_SHORT	PLC switch X (IN) 17 to 32	--	--	RW	0x0000 to 0xFFFF
M_SSEC_UP_PLCSW_OUT0	T_SHORT	PLC switch Y (OUT) 1 to 16	--	--	RW	0x0000 to 0xFFFF
M_SSEC_UP_PLCSW_OUT1	T_SHORT	PLC switch Y (OUT) 17 to 32	--	--	R	0x0000 to 0xFFFF